



SCHOOLING STANDARD  
ASSEMBLY INSTRUCTIONS

800.611.6109

[www.horsejumps.net](http://www.horsejumps.net)



**Step #1**

Remove the items from the package and check the contents. See list of contents on the back page.



**Step #2**

Set the Post into the PolyPro jump foot.



**Step #3**

Attach washer to bolt and slide through the hole provided on the PolyPro foot and base of standard.



**Step #4**

Slide washer onto bolt on opposite side and attach the nut. Hand tighten as much as possible



**Step #5**

Use a ratchet or wrench to securely tighten nut. This will hold the feet onto the jump and create a rugged base of support.



**Step #6**

Slide the side post into the provided space on the PolyPro foot.



**Step #7**

Attach washer to bolt and slide through the hole provided.



### Step #8

Slide washer onto bolt on opposite side and attach the nut. Hand tighten as much as possible



**Repeat steps 6-8 to attach the other side support.**



### Step #9

Slide the base plate over the underside of the PolyPro foot. If desired, sand or rocks can be placed inside the foot for additional weight prior to inserting the base plate.



### Step # 10

Turn assembled standard back to the upright position and repeat all of these steps on the remaining standard(s)

Package Contents:

- 2 PolyPro Jump Feet
- 4 Side Supports
- 12 Washers
- 6 Bolts
- 6 Nuts
- 2 Base Plates